



File Name: bose surround system manual.pdf

Size: 3604 KB

Type: PDF, ePub, eBook

Category: Book

Uploaded: 12 May 2019, 13:12 PM

Rating: 4.6/5 from 639 votes.

Status: AVAILABLE

Last checked: 14 Minutes ago!

In order to read or download bose surround system manual ebook, you need to create a FREE account.

[**Download Now!**](#)

eBook includes PDF, ePub and Kindle version

[Register a free 1 month Trial Account.](#)

[Download as many books as you like \(Personal use\)](#)

[Cancel the membership at any time if not satisfied.](#)

[Join Over 80000 Happy Readers](#)

Book Descriptions:

We have made it easy for you to find a PDF Ebooks without any digging. And by having access to our ebooks online or by storing it on your computer, you have convenient answers with bose surround system manual . To get started finding bose surround system manual , you are right to find our website which has a comprehensive collection of manuals listed.

Our library is the biggest of these that have literally hundreds of thousands of different products represented.



Book Descriptions:

bose surround system manual

Changes or modifications not expressly approved by Bose Corporation could void the user's authority to operate this equipment. No part of this work may be reproduced, modified, distributed or otherwise used without prior written permission. E N G. Use the power cord for your region. NOTE If any part of the product is damaged, do NOT use it. Contact your authorized Bose dealer or Bose customer service. To purchase these accessories, visit Bose.com or contact your local Bose dealer. CAUTION Only use Bose hardware to mount the speakers. Using unauthorized mounts may damage your Bose system and its components. The receivers come preset to a left and right channel out of the box. You can use the switch on the front of the receiver to adjust the channel settings. Choose your connection method from the table below. SOUNDBAR CONNECTION METHOD Connect using the Bose Music app see page 16. You hear sound coming from the surround speakers. NOTE If you don't hear sound from the surround speakers, see "Troubleshooting" on page 25. E N G. ADAPTiQ audio calibration customizes the sound of the system to the acoustics of your listening area by taking five audio measurements. Follow the app instructions. Use the Settings menu If you later connect the optional Bose Bass Module 500, Bose Bass Module 700 or Acoustimass 300 bass module, or move the speakers or move any furniture, run ADAPTiQ audio calibration to ensure optimal sound quality. TIP If you later connect the optional Bose Bass Module 500, Bose Bass Module 700 or Acoustimass 300 bass module, or move the speakers or move any furniture, run ADAPTiQ audio calibration again to ensure optimal sound quality. CAUTIONS Do NOT allow liquids to spill onto the surround speakers or into any openings. Do NOT use any sprays near the surround speakers. Do NOT use any solvents, chemicals or cleaning solutions containing alcohol, ammonia or abrasives. <http://www.vacumatic.com.au/documents/computer-operating-manual.xml>

- **bose surround speakers manual, bose surround speakers 700 manual, bose sound system manual, bose 1 2 3 surround sound system manual, bose surround system manual, bose surround system manual, bose surround system manual, bose surround sound system manual, bose acoustimass surround sound system manual.**

Move the surround speakers and soundbar away from possible interference wireless routers, cordless phones, televisions, microwaves, etc.. Place the surround speakers according to the placement guidelines see page 10. Firmly insert the adapters into the speakers. Place the surround speakers according to the placement guidelines see page 10. Test different sources if available. After correcting your problem, you must rerun ADAPTiQ audio calibration see page 18. If you hear a different error message, contact Bose customer service for further instructions. E N G. Opening or removing covers may expose you to dangerous voltages or other hazards. Please call Bose to be referred to an authorized service center near you. 15. To prevent risk of fire or electric shock, avoid overloading wall outlets, extension cords, or integral convenience receptacles. Save all packing materials for possible future use. The original packing materials provide the safest way to transport your speaker system. If any part of the product appears damaged, do not attempt to use the system. Notify Bose or your authorized Bose dealer immediately. Portable CD players often use a 3.5 mm stereo headphone jack, instead of the RCA jacks found on larger components. Turning on different sources in more than one room Let's say you have a two room system rooms A and B and the entire system is off. To turn on a different source in each room 1. Customer Service For additional help in solving problems, contact Bose address list enclosed in the product packaging for correct phone numbers. Details are provided on the warranty card that came with your system. Please fill out the information section on the card and mail it to Bose Corporation. Cleaning the Lifestyle Clean the

surface of your speakers with a soft, damp cloth. Do not use any sprays near the system. Please read this owner's guide carefully and save it for future reference. <http://www.plunge-in.at/userfiles/computer-operation-manual-pdf.xml>

The exclamation point within an equilateral triangle alerts the user to the presence of important operating instructions. As with any electronic products, use care not to spill liquids into any part not suitable for children under age 3. Contact your physician if you have questions on whether this device is neither designed nor tested for use outdoors, in recreational vehicles, or in boats. Please check your local building codes for the correct type of wire and cable required for in-wall installation. Important Safety Instructions: Keep these instructions. Heed all warnings. Follow all instructions. Do not use this apparatus near water. Clean only with a dry cloth. Do not block any ventilation openings. This equipment generates, uses, and can radiate radio frequency energy and, if not installed properly, may cause interference with other equipment. Changes or modifications not expressly approved by Bose Corporation could void the user's authority to operate this device. This device complies with part 15 of the FCC Rules and Industry Canada license exempt RSS standards. Operation is subject to the following two conditions: 1. This device may not cause harmful interference, and 2. This Class B digital apparatus complies with Canadian ICES-003. This device complies with FCC and Industry Canada RF radiation exposure limits set forth for general population. It must not be colocated or be operating in conjunction with any other antennas or transmitters. The temperature range of this product is 32°F (0°C) to 113°F (45°C). This symbol means the product must not be discarded as household waste, and should be disposed of properly. English: 3. Names and Contents of Toxic or Hazardous Substances or Elements. Toxic or Hazardous Substances and Elements. Lead, Mercury, Cadmium, Hexavalent Chromium, Biphenyl, Polybrominated, PCBs, Metal parts, Plastic parts, Speakers, Cables. Part Name: O Indicates that this toxic or hazardous substance contained in all of the homogeneous materials for this part is below the limit.

X Indicates that this toxic or hazardous substance contained in at least one of the homogeneous materials used for this part is. Please complete and retain for your records. We suggest you keep your receipt with this owner's guide. HDMI is a trademark or registered trademark of HDMI Licensing LLC in the United States and other countries. Manufactured under license from Dolby Laboratories. Dolby and the double-D symbol are trademarks of Bose Corporation in the U.S. and other countries. WiFi is a registered mark of the WiFi Alliance. No part of this work may be reproduced, modified, distributed, or otherwise used without permission. Introduction. System Features. 7. Unpacking the system. 8. Placement guidelines. 9. Sample system placement. 9. Attaching the rubber feet to the Acoustimass module. 10. Connecting the Acoustimass module to power. 11. Setting Up the Speakers. Connecting the front speakers. 12. Connecting the rear speakers. 13. Wall mounting the speakers. 13. Setting Up the Console. Connecting the console to your TV's HDMI ARC connector. 14. TVs without an HDMI ARC connector. 15. Use a secondary connection in the following configurations. 15. Connecting the console to other sources. 15. Connecting to non-HDMI compatible sources. 16. Audio sources. 16. Connecting the console to power. 16. Starting Up the System. Installing the remote control's batteries. 17. Powering on the system. 17. Finishing Setup. Checking for sound. 18. Changing the language on the console. 18. English. 5. Using the System. Remote control buttons. 20. Programming the universal remote control. 21. Consumer Electronics Control. 21. Test your HDMI-connected sources for CEC. 22. Program the remote to control your source. 23. Source selection. 24. Select a source connected to your TV. 24. Universal source buttons and console connectors. 24. Adjusting the volume. 25. Function buttons. 25. Programming a non-Bose remote control. 25.

Getting System Information from the Display. Understanding messages on the display. 26. Using the System menu. 26. Error messages. 28. Acoustimass module status indicator. 28. Care and Maintenance. Troubleshooting. 29. Factory reset the system. 31. Reset a source button on the

remote control. 31. Cleaning. 32. Customer service. 32. Limited warranty. 32. Technical information. 32The CineMate 520 system delivers spacious, true 5.1 surround sound from small, System FeaturesInternet radio, music services where available and your music library. If you have. Key BenefitsEnglish 7Unpacking the system. Carefully unpack the carton and confirm that the following parts are includedAcoustimassCenter speaker. Console power cord. Universal remote control. Console. Front speaker cable. HDMI cable. Rear speaker cable. Rubber feet. The appropriate power cords for your region are supplied. Contact your authorized. Refer to the contact sheet inPlacement guidelinesVibration can cause the. Acoustimass module to move, particularly on smooth surfaces likeFront speakersCenter speakerRear speakersConsole. Do NOT place the TV on top ofSample system placement. English 9. Attaching the rubber feet to the. Acoustimass module. Attach the rubber feet to the Acoustimass module to protect your floor.Rubber foot. Bottom of Acoustimass moduleConnecting the Acoustimass moduleEnglish 11Connecting the front speakersSpeaker Connections connector on the console.Connecting the rear speakersSpeaker Connections connector on the console. Wall mounting the speakers. To purchase these accessories, contact your local Bose dealer or visitEnglish 13Connecting the console to your TV's. HDMI ARC connectorTVs without an HDMI ARC connector. If your TV does not have an HDMI ARC connector, you may need to make aUse a secondary connection in the following configurationsRefer to your TV owner's guide for more information.Connecting the console to other sources.

If your source is nonHDMI compatible, use different audio and video cablesConnect other sources to theEnglish 15Connecting to nonHDMI compatible sources. If your source is nonHDMI compatible, connect it to your TV using audio and videoRefer to your TV owner's guide for more information. Tip If your source has IN and OUT audio connector panels, use audio OUT. Audioonly sources. If your audioonly source, such as a media or CD player, is nonHDMI compatible,You can use anYou can access these settings usingConnecting the console to powerInstalling the remote control's batteriesPowering on the system. PressThe console powers on. The display defaults to CBL SAT for first time power on. Otherwise, the displayYou can disable. AUTO OFF using the System menu see page 26. English 17Checking for soundTV input. You may need to use a different remote.Check that no sound is coming from the TVChanging the language on the console. Use the remote control to change the language on the console.Tip Look for theThe ADAPTiQ audio calibration customizes the sound of the system to theDuring the ADAPTiQ audio calibration, a microphone on the top of theEnglish 19Remote control buttons. Use the remote to control sources connected to your system, adjust the systemSource selection. Selects a sourceToggles betweenNavigation pad. Lists recorded. DVR programs. System menu. Displays the Internet. TV home page. Previous channel,PlaybackTV aspect ratio. Teletext mode. Closed captioningFunction buttonsProgramming the universal remote control. Consumer Electronics Control. The system supports Consumer Electronics Control CEC. CEC allows you toYour source may support CEC, but refer to it with a different name. Refer to yourCEC controls sources connected toRefer to yourEnglish 21Test your HDMIconnected sources for CEC. Test each of your sources for CEC using the remote control. Refer to your sourcePower on your TV.The source button glows. The source and system power on.

If your source does not perform one of the functions, program the remoteProgram the remote to control your source. If your source does not support CEC, you can program the remote to controlFor example, to program your TV, press and hold. Only the appropriate source button glows.Repeat steps 3 and 4.Press and to navigate. Press and to navigate.Press and to navigate.If your source responds to basic functions, pressIf your source does not respond. Use the remote control's code scanner to find the code for your source.English 23Source selection. You can switch between sources by pressing the appropriate source button on theIf your source is connected to the console and does not use CEC, follow thisThe source button glows.The source powers on. Select a source connected to your TV. If your source is connected to your TV, follow this procedure to select thePressYou may need to pressOn some TVs,Universal source buttons andThe source buttons on

your remote control correspond with the connectors onFor example,HDMI connector. Your source buttons work with any source that is connected to the correspondingIf you are using the optical, coaxial, or analog connectors, you must set the inputYou can access these settings using the System menuAdjusting the volume. On the remote controlNote If you hear sound coming from your TV, see "Troubleshooting" on page 29. Function buttons. The red, green, yellow and blue buttons on the remote control correspond with theProgramming a nonBose remote controlRefer to your nonBose remote control owner's. Once programmed, the nonBose remote controls basic functions such as power. English 25Understanding messages on the display. The display on the front of the console allows you to access the System menu andUsing the System menu. AUTO OFF, change the language, set the coaxial, analog and optical inputs for aDisplay.

System stateEnhance dialogue Increases the level of dialogue andSmart volume Reduces the range of volume levels in aAdjusts the audio delay to synchronize audio and video.Off Disables CEC.Disable The system will not automatically power off.Headphones Sets theDisconnect your headphones when not in use.Display. System stateEnglish 27Error messages. Display. System stateThe source is not connected to the console, or theThe source is not connected to theRefer to the contactAcoustimass module status indicator. The status indicator on the back of the Acoustimass module provides informationIndicator activity. Acoustimass module state. Amber. Connected to the console. Blinking amber. Disconnected from the console. Slow blinking amber. Available to make a wireless connection to the console. Red. System error.Troubleshooting. Problem. What to do. No powerNo sound. Sound isRemoteUnmute the system. Increase the volume. Plug the Acoustimass module and console into a live AC mains outlet. Insert the HDMI cable into a connector on your TV labeled ARC or Audio. Return Channel. If your TV does not have an HDMI ARC connector, use aIf using a secondary audio cable, insert the cable into a connector on your. TV labeled Output or OUT, not Input or IN. Secure all cable connections on the speakers, TV and connected sources. If your source is connected to your TV, select the correct TV inputDisconnect headphones when not in use.If connecting your source through theIf you are connecting headphones to theHeadphones using the System menu see page 26. If you see the error message Cannot find Acoustimass, pair the. Acoustimass module with the console see page 30. Factory reset the system see page 31. Insert the HDMI cable into a connector on your TV labeled ARC or. Audio Return Channel if available. Turn off your TV speakers refer to your TV owner's guide. Decrease your TV volume to its lowest setting.English 29Problem. What to do.

Poor orIntermittentThe Acoustimass module and console are paired at the factory. However, if youPlug in Acoustimass appears on the display.After the Acoustimass module connects to the console, Pairing completeFactory reset the systemThe system resets.Reset a source button on the remote control. If you are experiencing problems with a source button on the remote control, resetAfter performing this procedure, your source button is in CEC mode.Only the appropriate source button glows.The Service and Data connectors are for service use only. Do not insert any cablesEnglish 31Cleaning. Do not use any solvents, chemicals, orCustomer service. Refer to the contact sheet inLimited warranty. Your system is covered by a limited warranty. Details of the limited warranty arePlease refer to theFailure to register will not affect your limitedThe warranty information provided with this product does not apply in Australia and. Technical information. Power rating 100240V. Console. Power rating 100240VEnglish 33Lea atentamente esta guía del usuario y guardela para consultarla enEl signo de exclamacion dentro de un triangulo equilatero avisa al usuario de que existen instrucciones deAl igual que con cualquier producto electronico, evite que seLa exposicion a liquidos puede provocar averias oEvite utilizar losNo adecuado para ninos menores de 3 anos.Consulte a su medico si tiene alguna duda acerca de losNo esta disenado ni ha sido probado para uso al aire libre niInstrucciones de seguridad importantesGuarde estas instrucciones. Tenga presentes todas las advertencias. Siga todas las instrucciones. No utilice este aparato cerca del agua. Limpielo solo con un trapo seco. No bloquee las aberturas de ventilacion.

Realice la instalacion de acuerdo con las instrucciones del fabricante.

Lleve el dispositivo a reparar si presenta algun dano

Nota S
Estos limites estan diseñados para ofrecer una proteccion razonable
Este equipo genera, utiliza y puede irradiar
No obstante, no se puede garantizar
Si este equipo ocasiona
Los cambios o modificaciones no aprobados expresamente por Bose Corporation podrian anular la autorizacion
El dispositivo cumple la parte 15 de las normas de la FCC y de exencion de licencias RSS de Industry Canada. El funcionamiento esta sujeto a las dos condiciones siguientes

- 1 Este dispositivo no puede causar interferencias

Este aparato de Clase B cumple la especificacion canadiense ICES003. Este dispositivo respeta los limites de exposicion a la radiacion de radiofrecuencia establecidos por la FCC y las

No debe ubicarse ni utilizarse junto a
La eliminacion y

Espanol 3
PDF Version 1.7. Linearized Yes. Create Date 20140625 1459140400. Creator Adobe InDesign CC Windows. Modify Date 20140625 1459300400. Has XFA No. Metadata Date 20140625 1459300400. Creator Tool Adobe InDesign CC Windows. Document ID uuida2e3607cd338417282711ac17f3265d6. Instance ID uuid8cbafbd3bf8c43d49c8d95faecb5eec5. Producer Adobe Acrobat Pro 11.0.0. Page Count 35. Ask your question here. Provide a clear and comprehensive description of the issue and your question. The more detail you provide for your issue and question, the easier it will be for other Bose Surround Speakers owners to properly answer your question. Ask a question About the Bose Surround Speakers This manual comes under the category Speakers and has been rated by 1 people with an average of a 6.2. This manual is available in the following languages English. Do you have a question about the Bose Surround Speakers or do you need help. Ask your question here Bose Surround Speakers specifications Brand The distance between the two devices that exchange data can in most cases be no more than ten metres. When the volume exceeds 120 decibels, direct damage can even occur.

The chance of hearing damage depends on the listening frequency and duration. This makes it possible to create a 5.1 effect with only 1 speaker. ManualSearcher.com ensures that you will find the manual you are looking for in no time. Our database contains more than 1 million PDF manuals from more than 10,000 brands. Every day we add the latest manuals so that you will always find the product you are looking for. Its very simple just type the brand name and the type of product in the search bar and you can instantly view the manual of your choice online for free. ManualSearcher.com If you continue to use this site we will assume that you are happy with it. Read more Ok. View and Download Bose Lifestyle SoundTouch 535 setup manual online. Lifestyle SoundTouch 535 Stereo System pdf manual download. View and Download Bose Lifestyle 535 Series III setup manual online. Bose. Home Theater System Bose Lifestyle SoundTouch 535 Operating Manual. View online or download Bose Lifestyle 535 Series III Setup Manual. Manuals and User Guides for Bose Lifestyle 535 Series III. Using Soundtouch40. Home Theater System Bose Lifestyle Soundtouch 535 Operating Manual. 34 pages. Stereo System Bose Lifestyle SoundTouch 535 Setup Manual. 24 pages . Enter audio nirvana with the Lifestyle 650 Home Entertainment system. We have the following Bose Lifestyle 535 Series II Home Entertainment manuals available for free PDF download. Buy Bose Lifestyle 535 Series II Home Entertainment System Discontinued by Manufacturer Home. If you need bose manuals, stay here!. Lifestyle SoundTouch 525 535 Owner manual. Reload to refresh your session. Reload to refresh your session.